


madimack

mower





Quick Start Guide







Please read this quick start guide carefully or refer to the full manual for further support/instructions

STEP 1 | Place the charging station in an open area


Random Path



STEP 2 | Install the boundary wire and connect to power supply



STEP 3 | Learn about the control panel under the lid of robotic mower




STEP 4

General settings for first use

Reminder: File your PIN code somewhere safe for future usage.

Power on the mower and finish initial setup.




STEP 5

Connect to APP and set your schedule
(Move to Step 6 if APP is not necessary)

Press to enter the menu and select “WiFi setting”.



Note:
Scan the QR code to download the “InverGo” App in iOS App Store/Google Play.



STEP 6

Set the cutting height and start mowing

Place mower on charging station and adjust the cutting height.
Press and , select , robot starts mowing in Random mode.

WARNING:
Press “STOP” button for emergency, do not press it when robot saving map on station.



Scan the QR code
for the User Manual